



LABOR-INTENSIVE REPL.

Make	Model	Year	Battery Location														
			Under Hood					Passenger Area			Rear			Trunk			
			Under Hood	In Active Cooling Box	By Fire-wall	Under Air Filter	Under Fuse Box	Under Washer Bottle	Under Driver Seat	Behind Pass. Seat	Under Rear Seat	In Rear	Behind Left Tire*	Under Spare Tire	In Wheel Well	In Trunk	
Audi	A3	06			•												
	A4	06-97			•												
	A4 Quattro	06-98			•												
	A6	06-95			•												
	A6 Quattro	06-98			•												
	A8	03-97														•	
	A8 Quattro	06-98														•	
	Allroad Quattro	05-01			•												
	RS6	04-03			•												
	S4	06-00, 94-92			•												
	S6	03-02, 97-95			•												
	S8	03-01			•												
TT	06-00						•										
TT Quattro	06-04						•										
BMW	300 Series	07-96														•	
	500 Series	07-82														•	
	600 Series	07-04														•	
	700 Series	07-78														•	
	Alpina Roadster	03														•	
	M3	06-88														•	
	M5	03-00														•	
	M6	07-06														•	
	X3	07-04											•			•	
	X5	07-00											•			•	
	Z3	02-96														•	
	Z4	07-03														•	
Z8	03-00														•		
Buick	Century	05-97	•														
	LeSabre	05-00									•						
	Lucerne	06									•						
	Rainier	07-04		•													
	Regal	04-90	•														
	Rendezvous	07-02	•														
	Riviera	99-95	•														
Terraza	07-05						•										
Cadillac	Allante	93-87									•						
	Catera	01-97	•														
	Deville	05-00, 85									•						
	DTS	07-06									•						
	Seville	04-98									•						
	Seville	93-91	•														
XLR	07														•		
Chevrolet	Cobalt	07-05														•	
	Colorado	07-04		•												•	
	Corvette	07-06														•	
	Corvette	96-90	•														
	Equinox	07-05	•														
	HHR	07-06									•						
	Impala	07-00, 96-94	•														
	Lumina	01-90							•								
	Lumina APV	96-90							•								
	Monte Carlo	07-95	•														
	SSR	06-04									•						
Trailblazer	07-02		•														
Uplander	06-05							•									
Venture	05-97							•									
Chrysler	300	07-05														•	
	300M	04-99														•	
	Cirrus	00-95														•	
	Condor	04-98														•	
	Intrepid	04-98														•	
	LHS	01-99														•	
	PT Cruiser	07-01				•											
Sebring	07-96														•		
Dodge	Charger	07-06														•	
	Intrepid	04-98														•	
	Magnum	07-05									•						
	Sprinter	06-03	•														
	Stratus	06-95														•	
Viper	06-92										•						

